


# HOW TO MEASURE YOUR DOOR

Please take the following measurements to determine the size of your new Clopay garage door.



## STEP #1

Measure door opening width and height in feet and inches. This determines the size of door needed. The rough opening should be the same size as the door.

1. Width \_\_\_\_\_ ft. \_\_\_\_\_ in.  
 Height \_\_\_\_\_ ft. \_\_\_\_\_ in.

## STEP #2

Measure for sideroom: 3<sup>3</sup>/<sub>4</sub>" is required on each side for installation of the vertical track for standard extension springs and EZ-Set Torsion Spring System™; 5<sup>1</sup>/<sub>2</sub>" required for installation on EZ-Set Extension Spring System™.

2. Left Sideroom \_\_\_\_\_ ft. \_\_\_\_\_ in.  
 Right Sideroom \_\_\_\_\_ ft. \_\_\_\_\_ in.

## STEP #3

Measure area labeled "headroom"—distance between the top of the door opening ("jamb header") and the ceiling (or floor joist). 10" is required for standard extension spring or EZ-Set Extension Spring System™, 12" is required for standard torsion spring and EZ-Set Torsion Spring System™. If you have restricted headroom, special hardware is available.

**NOTE:** If door height extends above the opening, the headroom measurement should be adjusted proportionately. **Additional headroom is required for installation of an automatic garage door opener.**

3. Headroom \_\_\_\_\_ ft. \_\_\_\_\_ in.

### HEADROOM REQUIREMENTS

Spring Type	12" Radius	15" Radius
Extension	10"	12"
Torsion	12"	14"
EZ-Set Torsion	12"	14"

## STEP #4

Measure area labeled "backroom"—distance is measured from the garage door opening toward the back wall of the garage (or first obstruction). Door height plus 18" is required. **Additional backroom is required for installation of an automatic garage door opener.**

4. Backroom \_\_\_\_\_ ft. \_\_\_\_\_ in.